

ARRIVAL SET-UP 3-2-1

Select Approach Plate on DU

MCDU: SELECT APPROACH or (CCD optional)

- Verify on MCDU that the Arrival is Programmed.
- LSK 6R will say Landing).
- Magenta Line (Activate Vectors?)

MCDU: PERFORM LANDING INIT (LSK 6R)

MCDU: SET FREQUENCY on PROG Page / Insert ILS ICAO

DC: NAV / Preview – Press NAV 1 or 2, then rotate CRS to inbound CRS.

- PREVIEW will be boxed.
- Not required on Golf Enhanced (ASC084)

DC: SET DA/MDA

- FLT REF on Display Controller
- Then BARO, dial DA and box it (ILS DA)

DC: HUD & EVS (optional)

- Landing Elevation / Flight Path Angle / AUTO / NUC Check